# SMART SENSOR BUSINESS

# Leuze electronic

the sensor people





Part no.: 50113678 AMS 304i 120 Optical distance sensor




Figure can vary

# Contents

- Technical data
- · Dimensioned drawings
- Electrical connection
- · Operation and display
- · Part number code
- Notes
- Accessories

# Part no.: 50113678 – AMS 304i 120 – Optical distance sensor

### **Technical data**

Basic data	
Series	AMS 300i
Application	Collision protection of cranes / gantry cranes Positioning of electroplating plants Positioning of high-bay storage devices Positioning of skillet systems and side-tracking skates
Characteristic parameters	
MTTF	31 years
Optical data	
Light source	Laser , Red
Laser class	2, IEC/EN 60825-1:2007
Measurement data	
Measurement range	200 120,000 mm
Accuracy	2 mm
Reproducibility (3 sigma)	1.5 mm
Max. traverse rate	10 m/s
Electrical data	
Performance data	
Supply voltage UB	18 30 V , DC
Interface	
Туре	PROFIBUS DP , SSI
PROFIBUS DP	
Transmission speed	0.0096 12 Mbit/s
SSI	
Clock frequency	50 800 kHz
Connection	
Number of connections	5 Piece(s)
Connection 1	
Type of connection	Connector
Designation on device	BUS IN
Function	BUS IN Data interface PROFIBUS IN
Thread size	M12
Туре	Male
No. of pins	5 -pin
Encoding	B-coded

## Part no.: 50113678 – AMS 304i 120 – Optical distance sensor

Connection 2	
Type of connection	Connector
Designation on device	BUS OUT
Function	BUS OUT Data interface PROFIBUS OUT
Thread size	M12
Туре	Female
No. of pins	5 -pin
Encoding	B-coded
Connection 3	
Type of connection	Connector
Designation on device	PWR
Function	PWR / SW IN/OUT Voltage supply
Thread size	M12
Туре	Male
No. of pins	5 -pin
Encoding	A-coded
Connection 4	
Type of connection	Connector
Designation on device	SERVICE
Function	Service interface
Thread size	M12
Туре	Female
No. of pins	5 -pin
Encoding	A-coded
Connection 5	
Type of connection	Connector
Designation on device	SSI
Function	Data interface SSI
Thread size	M12
Туре	Male
No. of pins	5 -pin
Encoding	B-coded
echanical data	
esign	Cubic
mension (W x H x L)	84 mm x 166.5 mm x 159 mm
busing material	Metal
et weight	2,450 g
pe of fastening	Through-hole mounting
peration and display	
rpe of display	LC Display LED
perational controls	Membrane keyboard
nvironmental data	
nbient temperature, operation	-5 50 °C


## Part no.: 50113678 – AMS 304i 120 – Optical distance sensor

-30 70 °C
90 %
IP 65
III
c UL US
90318020
27270801
27270801
EC001825
EC001825

### **Dimensioned drawings**

All dimensions in millimeters

Part no.: 50113678 – AMS 304i 120 – Optical distance sensor



A M 5 screw for alignment B Knurled nut with WAF 4 hexagon socket and M 5 nut for securing

C Optical axis


D Zero point of the distance to be measured

## Part no.: 50113678 – AMS 304i 120 – Optical distance sensor

#### **Electrical connection**


Connection 1	BUS IN
Type of connection	Connector
Function	BUS IN Data interface PROFIBUS IN
Thread size	M12
Туре	Male
Material	Metal
No. of pins	5 -pin
Encoding	B-coded

Pin	Pin assignment
1	NC
2	A (N)
3	GND P
4	B (P)
5	Shield



Connection 2	BUS OUT	
Type of connection	Connector	
Function	BUS OUT Data interface PROFIBUS OUT	
Thread size	M12	
Туре	Female	
Material	Metal	
No. of pins	5 -pin	
Encoding	B-coded	


Pin	Pin assignment
1	VP
2	A (N)
3	GND P
4	B (P)
5	Shield



Connection 3	PWR
Type of connection	Connector
Function	PWR / SW IN/OUT Voltage supply
Thread size	M12
Туре	Male
Material	Metal
No. of pins	5 -pin
Encoding	A-coded


### Part no.: 50113678 – AMS 304i 120 – Optical distance sensor

Pin	Pin assignment
1	VIN
2	I/O 1
3	GND
4	I/O 2
5	FE




Connection 4	SERVICE
Type of connection	Connector
Function	Service interface
Thread size	M12
Туре	Female
Material	Metal
No. of pins	5 -pin
Encoding	A-coded

Pin	Pin assignment
1	n.c.
2	RS 232-TX
3	GND
4	RS 232-RX
5	n.c.



Connection 5	SSI	
Type of connection	Connector	
Function	Data interface SSI	
Thread size	M12	
Туре	Male	
Material	Metal	
No. of pins	5 -pin	
Encoding	B-coded	

Pin	Pin assignment
1	DATA+
2	DATA-
3	CLK+
4	CLK-
5	FE



### **Operation and display**

### LEDs

LED		Display	Meaning	
1	PWF	Off	No supply voltage	

# Part no.: 50113678 – AMS 304i 120 – Optical distance sensor

LED		Display	Meaning	
	Green, flashing Voltage		Voltage connected / no measurement value output / initialization running	
		Green, continuous light	Device OK, measurement value output	
		Red, flashing	Device OK, warning set	
		Red, continuous light	No measurement value output	
		Orange, continuous light	No data transmission	
2	BUS	Off	No supply voltage	
		Green, continuous light	Bus operation ok	
		Green, flashing	Device not on the bus	
		Red, flashing	No data transmission	
		Red, continuous light	Bus error	

### Part number code

#### Part designation: AMS 3XXi YYY Z AAA

AMS	Operating principle: AMS: absolute measurement system
3XXi	Series/interface (integrated fieldbus technology): 300i: RS 422/RS 232 301i: RS 485 304i: PROFIBUS DP / SSI 308i: TCP/IP 335i: CANopen 338i: EtherCAT 348i: PROFINET RT 355i: DeviceNet 358i: EtherNet/IP 358i: EtherNet/IP 384i: Interbus
YYY	Operating range: 40: max. operating range in m 120: max. operating range in m 200: max. operating range in m 300: max. operating range in m
Z	Special equipment: H: with heating
AAA Interface: SSI: with SSI interface	

#### Note

A list with all available device types can be found on the Leuze electronic website at www.leuze.com.

### Notes

#### Observe intended use!

- This product is not a safety sensor and is not intended as personnel protection.
- The product may only be put into operation by competent persons.
- Only use the product in accordance with its intended use.

#### Part no.: 50113678 – AMS 304i 120 – Optical distance sensor

#### WARNING! LASER RADIATION - LASER CLASS 2

#### Never look directly into the beam!

The device satisfies the requirements of IEC 60825-1:2007 (EN 60825-1:2007) safety regulations for a product of **laser class 2** as well as the U.S. 21 CFR 1040.10 regulations with deviations corresponding to "Laser Notice No. 50" from June 24, 2007.

- Never look directly into the laser beam or in the direction of reflected laser beams! If you look into the beam path over a longer time period, there is a risk of injury to the retina.
- Do not point the laser beam of the device at persons!
- Interrupt the laser beam using a non-transparent, non-reflective object if the laser beam is accidentally directed towards a person.
- · When mounting and aligning the device, avoid reflections of the laser beam off reflective surfaces!
- CAUTION! Use of controls or adjustments or performance of procedures other than specified herein may result in hazardous light exposure.
- · Observe the applicable statutory and local laser protection regulations.
- The device must not be tampered with and must not be changed in any way. There are no user-serviceable parts inside the device. Repairs must only be performed by Leuze electronic GmbH + Co. KG.

#### NOTE

#### Affix laser information and warning signs!

Laser information and warning signs are affixed to the device. In addition, self-adhesive laser information and warning signs (stick-on labels) are supplied in several languages.

- Affix the laser information sheet to the device in the language appropriate for the place of use. When using the device in the US, use the stick-on label with the "Complies with 21 CFR 1040.10" note.
- Affix the laser information and warning signs near the device if no signs are attached to the device (e.g. because the device is too small) or if the attached laser information and warning signs are concealed due to the installation position.
- Affix the laser information and warning signs so that they are legible without exposing the reader to the laser radiation of the device or other optical radiation.
- For UL applications, use is only permitted in Class 2 circuits in accordance with the NEC (National Electric Code).
- Use as safety-related component within the safety function is possible, if the component combination is designed correspondingly by the machine manufacturer.

#### Accessories

### Connection technology - Connection cables

Part no.	Designation	Article	Description
50104171	KB SSI/ IBS-5000-BA	Connection cable	Suitable for interface: SSI, Interbus-S Connection 1: Connector, M12, Axial, Female, B-coded, 5 -pin Connection 2: Open end Shielded: Yes Cable length: 5,000 mm Sheathing material: PUR
50135243	KD PB-M12-4A- P3-050	Connection cable	Suitable for interface: PROFIBUS DP Connection 1: Connector, M12, Axial, Female, B-coded, 4 -pin Connection 2: Open end Shielded: Yes Cable length: 5,000 mm Sheathing material: PUR

## Part no.: 50113678 – AMS 304i 120 – Optical distance sensor

Part no.	Designation	Article	Description
50132079	KD U-M12-5A- V1-050	Connection cable	Connection 1: Connector, M12, Axial, Female, A-coded, 5 -pin Connection 2: Open end Shielded: No Cable length: 5,000 mm Sheathing material: PVC
50135248	KS PB-M12-4A- P3-050	Connection cable	Suitable for interface: PROFIBUS DP Connection 1: Connector, M12, Axial, Male, B-coded, 4 -pin Connection 2: Open end Shielded: Yes Cable length: 5,000 mm Sheathing material: PUR

## Reflective tapes for distance sensors

Part no.	Designation	Article	Description
50104362	Reflexfolie 500x500mm-S		Design: Rectangular Reflective surface: 500 mm x 500 mm Chemical designation of the material: PMMA Fastening: Adhesive

## Services

Part no.	Designation	Article	Description
S981001	CS10-S-110	Start-up support	Details: Performed at location of customer's choosing, duration: max. 10 hours. Conditions: Devices and connection cables are already mounted, price not including travel costs and, if applicable, accommodation expenses. Restrictions: No mechanical (mounting) and electrical (wiring) work performed, no changes (attachments, wiring, programming) to third-party components in the nearby environment.
S981005	CS10-T-110	Product training	Details: Location and content to be agreed upon, duration: max. 10 hours. Conditions: Price not including travel costs and, if applicable, accommodation expenses. Restrictions: Travel costs and accommodation expenses charged separately and according to expenditure.

Note
A list with all available accessories can be found on the Leuze electronic website in the Download tab of the article detailed page.